

2/10




FIG. 2

3/10






FIG. 3

4/10

FIG. 4








FIG. 6

7/10





FIG. 7

8/10

PROCESS SETTING CODE (hex)	PRESENT IN OWN DEVICE ATTRIBUTE (PROPERTY LIST)	ABSENT IN OWN DEVICE ATTRIBUTE (PROPERTY LIST)	BASIC MEANING OF PROCESS SETTING CODE
0x00	NOT PERMITTED		NG
0x01	PERMITTED		OK
0x02 - 0x7f	++ NUMBER OF LINES	NUMBER OF LINES += VALUE	Jump if not exist
0x80	NOT PERMITTED	++ NUMBER OF LINES	NG if exist
0x81	PERMITTED	++ NUMBER OF LINES	OK if exist
0x82	++ NUMBER OF LINES	NOT PERMITTED	NG if not exist
0x83	++ NUMBER OF LINES	PERMITTED	OK if not exist

FIG. 8

FIG. 9



10/10

PROPERTY DEFINITION DATA (or PROPERTY ID)	PROCESS SETTING CODE (hex)
AAAA	0x02
BBBB	0x81
CCCC	0x02
DDDD	0x83
EEEE	0x82
FFFF	0x82
GGGG	0x81

(a) (b) (c)

FIG. 10